


Break the Plate

Time Setting and Wi-Fi Connection

Instructions

- Turn off main power with switch located on the bottom right corner of the back of the cabinet.
- ***Gently*** remove Game SD Card from Master Controller Unit and put aside to be reused later. See photos below.



- ***Gently*** insert Time Set SD Card (*supplied with these instructions*) into the Master Controller Unit.
- Insert USB keyboard (wireless is preferred). See photo below.




- Turn game on.
- CA logo should briefly appear on bottom monitor.
- Please wait for Time Zone Menu to appear.
- If correct time & date is shown, use space bar to enter “Yes”.
- If incorrect time is shown, hit Tab on keyboard to select “No”. Then hit Space Bar on keyboard to enter. Note: Shift + Tab to go back.
- Enter location name and name of city where game is located.
- Select Scan to find your Wi-Fi Network. If your Wi-Fi network is not listed, enter it manually into the SSID field.
- Select your Wi-Fi Network and enter password.
- Select DHCP option.
- Then select “Save”.
- The system will now reboot on its own.
- The screen will again ask if time is correct. If so, select “Yes”.
- Let game sit for one minute before turning the power off.
- After one minute, turn the power off.
- **Gently** remove Time Set SD Card.
- **Gently** reinsert Game SD Card that you removed previously.
- Turn power back on.

Note: Please keep the Time Set SD Card in case it is needed in the future.

After the game boots up, reconnect to your Wi-Fi by following the instructions below. *Keeping your game connected to Wi-Fi will enable Coastal to send software updates automatically and will also enable our service department to diagnose your game if there is a service issue.*

Wi-Fi Connectivity Instructions

- Go into Main Menu and select Internet Options.
- If your internet options have already been set, the screen will say “Status: Online”. Your screen should look like this (see photo below):



- **If this is not the case, then please proceed with the following instructions.**
- Enter location name (D&B Store # and name of city where game is located).
- Select Scan to find your Wi-Fi Network. If your Wi-Fi network is not listed, enter it manually into the SSID field.
- Select your Wi-Fi Network and enter password.
- Select DHCP option.
- Then select "Save".
- Turn the power off.
- Wait one minute and then turn the power back on.
- The game is now ready to be played.

BTP WI-FI set up

1. As the game is starting up, repeatedly press Ctrl + C until it exits to the terminal. You should see a black screen with a prompt that looks like:

```
pi@CoastalPi:~ $
```

2. Type the following command exactly and press Enter:

```
sudo nano /etc./wpa_supplicant/wpa_supplicant.conf
```

a. If typed correctly, you should see something like:

```
country=US
ctrl_interface=DIR=/var/run/wpa_supplicant GROUP=netdev
update_config=1
```

b. If you make a mistake, press Ctrl + X to exit and try again.

3. Next you must enter the network settings as seen below.

Replace "name_of_wifi_network" with your actual Wi-Fi network name (SSID).

Replace "password" with your Wi-Fi password.

```
country=US
ctrl_interface=DIR=/var/run/wpa_supplicant GROUP=netdev
update_config=1
```

```
network={
    ssid="name_of_wifi_network"
    psk="password"
}
```

4. Press Ctrl + X to exit. When asked to save changes, press Y and then press Enter.

5. Wait 30 seconds, then reboot the device.