





Coastal Part#	DESCRIPTION	ACE #	PICTURE
3585	BULLS EYE CRACKSHOT COMPUTER, 2 MON 2 PLAYER	Computer MT-A5167 / 1.07.020 BCS--CP750	
5028	COMPUTER, DX 2 PLAY 1 MONITOR	Computer SSY MT-A5168 / 1.07.028 BCS--CP750	
3718	I/O BOARD	BCS--IOB012	
3716	I/O BOARD 2P-1M -	BCSDX-- IOB023	
3717	GRAPHIC CARD	BCS-- GRC1030	
3365	POWER AMPLIFIER	BCS--PWGA025	
3719	MENU BOARD	BCS--4KB05	 
3177	FAN	BCS--CF06	
	12V POWER SUPPLY	BCS--12VPS70	 
	24V POWER SUPPLY	BCS--24VPS40	 
	DVI CABLE	BCS--DVIC10	
	SERIAL PORT CABLE	BCS--SPC09	
3793	POWER SWITCH	BCS--PRS02	
3801	SOLENOID VALVE	BCS--SLVA15	
3392	OIL WATER PROCESSOR	BCS--OWP30	
3800	HAND VALVE	BCS--HVA05	

3081	AIR PIPE	BCS--ARP01M	
	SPEAKER	BCS--SK035	
3147	ROUND BUTTON	BCS--RB05	
3175	TRIANGLE BUTTON	BCS--TB06	
3548	COMPLETE GUN Assembly **BLUE**	BCS--CBG250	
3549	COMPLETE GUN Assembly **RED**	BCS--CRG250	
3271	GUN CABLE COVER	BCS--GCC15	
3720	SMALL CAMERA	BCS--SMC013	
3532	AIR COMPRESSOR 220V 50HZ	1.12 004 0118	
3708	AIR COMPRESSOR	BCS--CPS110	
3416	GUN CABLE	BCS--GC40	
3609	LASER SET (#300)	1.09.002.0208 + 1.14.003.0	
3705	49" LCD SCREEN	BCS--49LCD5600	
	GUN UPPER COVER	BCS--GUC05	
3607	*BLUE* GUN COVER	BCS--BGC20	
3608	*RED* GUN COVER	BCS--RGC20	

5941	BULLSEYE CRACK SHOT GUN SHELL		
5742	BULLSEYE CRACK SHOT METAL GUN HOLDER	101077.0029	
3615	GUN TRIGGER	BCS--GT02	
3618	GUN LASER TUBE	BCS--GLST04	
3613	GUN CYLINDER ASSEMBLY	1.14.009.095F	
	GUN T SHAPE PLATE	BCS--GTSP10	
	GUN BUMPER A	BCS--GBUPA03	
	GUN BUMPER B	BCS--GBUPB03	
	STAINLESS EXPLOSION-PROOF PIPE	BCS--SEPP15	
3617	SPRING 0.3*6*20	BCS--S0.301	
3784	GUN RESTORING SPRING	BCS--GRS01	
3792	MICRO SWITCH	BCS--MS02	
3610	BEARING 4*6*5	BCS--BR45602	
3393	CONSOLE WHITE RECTANGULAR ACRYLIC. GOES WITH AA-G&G-BES -TA07	WRA08	
5722	ACE SPORT PLEXI FOR BULLSEYE CRACK SHOT	1.03.073.0032	
5723	BULLSEYE CRACK SHOT BLUE SPEAKER PLEXI	1.03.073.0008	

6283	MONITOR PLEXI 49"	1.03.073.0014	
3469	Bullseye shot crack--Transparent acrylic panel for console		