

















Coastal Part#	DESCRIPTION	ACE #	PICTURE
3417	DINO ERA 4 PLAYER WATER R & L SIDE CABINET DECALS	DN4-CD40	
3313	DINO ERA 4 PLAYER WATER LIGHT BOX DECAL	DN4-LD20	
3272	DINO ERA 4 PLAYER WATER COIN DOOR DECAL	DN4-CDD15	
5675	DINO ERA 75" LEFT FLOOR DECAL	WX030300518	
5676	DINO ERA 75" RIGHT FLOOR DECAL	WX030300524	
3690	DINO ERA 4 PLAYER WATER BACK HEADER FOR MARQUEE	BH200	
	BACK HEADER	BH200	
6237	BLACK BASE	1.03.038.0034	
5677	DINO ERA 75" BLACK DISK UNDER SEAT ABOVE LEDS	WX010200085	
3751	Left Side water shield	WS4--LSWS75	
3752	Right Side water shield	WS4--RSWS75	
3576	MAIN PC 4 PLAYER	DNWS4P--CPU075	
	DINO ERA W4P-IO Board		
	I/O BOARD DINO ERA	DE-IO001	
3368	TOP LONG PVC COVER, DINO ERA 4PLAYER	DE4P-PVC01 - old version before 2023	

3454	TOP LONG PVC COVER, DINO ERA 4PLAYER	DE4P-PVC02 2023 OR NEWER	
3774	3 PLAYER 110V WATER PUMP		
3775	4 PLAYER 220V WATER PUMP	W4P-029	
3390	DINO ERA 4 PLAYER WATER GRASS	GF3L4L30	
3709	SEAT SHAKING MOTOR	SSM-DH12	
3680	3 PLAYER COLORFUL LED STRIP 5M/1 ROLL	CLED35	
3675	POWER SUPPLY KIT		
3367	UV LAMP	UVL25	
3632	4 PLAYER WATER GUN BASE FOR 1 OR 2 PLAYER POSITION, DINO ERA	GBM50-12P OR GBM50--BigP12	
3633	4 PLAYER WATER GUN BASE FOR 3 OR 4 PLAYER POSITION, DINO ERA		
3314	EMI FILTER - DINO ERA	PF30A-20	
3312	CIRCUIT BREAKER 4 PLAYER	WCP-65'CB02	
5830	Gun Gills (Dino Era)	1.14.003.0042	
5429	Start Button	1.09.002.0142	
5432	DINO ERA BUTTON FIXATION	1.14.003.0043	
3215	LARGE BOTTOM FILTER (Inside Part) - DINO ERA -	W4P-011	

5741	Large Bottom Filter	W4P-008	
3214	Large Water Filter for Water Tank use (3pls and 4pls water machine)	W4P-007	
5717	Water Tub	WG010300010	
6008	SSR-10DD Relay	SRR10DD15	
6009	SSR-25DA Relay	SRR25DA15	
5968	Potentiometer	WS-Poten015	
5740	Water Bucket Switch	WBS05	
3178	Large Pipe Clip	W4P-009	
5970	Small Pipe Clip	W4P-010	
3692	Water Steam Assy	W4P-028	
3634	Gun handle Metal part	GH50	
	Gun Base Metal Part	GBM50	
	Gun tube	GT60	
	Big Gear B	BGB7	
	Tightening Nut	TN5	

	Left & Right GearA	LR5	
	Up & Down Gear	UDG5	
	Bearing6810-ZZ	B6810	
	Gear B	GB5	
	Fuse	Fuse01	
	Pin for Water Gun	WTGP01	
3783	Speaker	SK05	
3247	AMPLIFIER 12V 20W	APL015	
	12V Power Supply	12VPS40	
	24V Power Supply	21VPW40	
	48V Power Supply	48VPS35	
	24V Valve	24VAL18	
	Cooling Fan	CF06	
	Complete PVC Gun Head 12mm (4/3pls) After 2023.01	CGH1225	
	Complete PVC Gun Head 10mm (4/3pls) before 2023	CGH1025	
	Water Filter Small (2-4pls)	WFS01	

	Water Filter Large (2pls)	WFL1.5	
3133	Gun Stopper Rubber Wheel A (Left-Right)	GSR04	
3118	Gun Stopper Rubber Wheel B (Up - Down)	GDR03	
	6808 Bearing	6808B10	
	Power Amplifier	PA30	
	IO Board	MB-MINIPCB V1.3	
	Speed Board	SPB20	
	Mother Board	MPCB230	
	Graphic Card	GC200	
	Top Perspex	TP50	
	Water Tray for Machine	WT175	
	Small Water Pump(2 players)	SWP150	
	Big Water Pump(3/4 players)	BWP200	
	Gun Tube	GT60	
	Complete Gun Mount/Arm & Hardware	CGM160	
	Bearing and Shaft and Mount	BFM80	
	Gun Base Metal Part	GBM50	

	Valve Solenoid Assy	VSA150	
	Water Exit Assy	WEA20	
	43'Monitor	43M450	
	Grasses for 2players	GF2L20	
	Bezel PVC Part	BZPVC15	
	Key Dongle	KD650	
3220	TK Handle including mechanical components	TKH10	
	Gun Bearing Assy -	GBA10	
	Gear C	GC05	
	Gear D	GD05	
	Up & Down Gear	UDG05	
	Left & Right Gear	LRG05	
	Bearing	GB08	
	Head Perspex	HP20	
	White LED Strip	WLED35	5M / 1 Roll
	Blue LED Strip	BLED35	5M / 1 Roll
	Speed Board	SPB20	